

Buttress Crown Cutter Dispense Instructions



The SpaceKraft tote arrives with a 2" buttress threaded dispense outlet. The dispense plug is colored blue.



Remove the blue 2" plug from the dispense outlet. You will find a 2" crown cutter tool affixed to the back of the plug.



Separate the 2" crown cutter from the plug and reinsert it into the dispense gland with the "teeth" pointing toward the liner membrane.



Open the knockout on top of the shuttle with your fist. You may have to score the outline with a knife. Be careful not to penetrate the bladder.



Lift up the knockout and the adapter will be taped underneath.



Screw the adapter into a standard 2 inch ball valve.



With the valve in the closed position begin threading the ball valve assembly into the dispense gland. (Note, here a quick connect has been attached to the outlet of the valve.)



Continue threading the ball valve assembly **clockwise** into the dispense gland.



Congratulations! You are now ready to dispense. Product flow can be controlled by opening/closing the 2" valve.